

Barracuda Message Archiver Panel Indicators, Ports, and Connectors

<https://campus.barracuda.com/doc/41102726/>


This article refers to Barracuda Message Archiver firmware version 5.0 or higher.

The illustrations in this article are based on current hardware models, however, models differ based on release date and may change in the future. If your appliance connections differ from those shown in this article, contact [Barracuda Technical Support](#) for additional information.

Barracuda Message Archiver Models 150, 350, 450, and 650

Front Panel Components

The following figure illustrates the Barracuda Message Archiver models 150, 350, 450, and 650 power and disk activity indicator lights:




The following table describes the Barracuda Message Archiver model 150 front panel power and disk activity indicator lights:

Component Name	Description
Power Button	Push to power on the appliance, tap to shut down.
Reset Button	Push for five seconds to safely reboot the appliance.
Power Indicator	Displays a solid blue when the system is powered on.
Disk Light	Displays a solid green light and blinks during disk activity.

Model 150 Rear Panel Ports and Connectors

The following figure illustrates the Barracuda Message Archiver model 150 rear panel ports and connectors:




The following table describes the Barracuda Message Archiver model 150 rear panel ports and connectors:

Port/Connector Name	Details
Power Supply	Power supply input.
Mouse Port	<i>Optional.</i> Mouse port.
Keyboard Port	<i>Optional.</i> PS2 keyboard connection.
VGA Port	<i>Recommended.</i> Video graphics array (VGA) monitor connection.
HDMI Port	<i>Optional.</i> HDMI video connection.
USB Ports (4)	<i>Optional.</i> USB device connection.
Network Port	Network connection.
Serial Port	<i>Optional.</i> Serial device connection.

Models 350 and 450 Rear Panel Ports and Connectors

The following figure illustrates the Barracuda Message Archiver models 350 and 450 rear panel ports and connectors:




The following table describes the Barracuda Message Archiver models 350 and 450 rear panel ports and connectors:

Port/Connector Name	Details
Power Supply	Power supply input.
Power Switch	Power switch.
Mouse Port	<i>Optional.</i> Mouse port.
Keyboard Port	<i>Optional.</i> PS2 keyboard connection.

USB Ports (2)	<i>Optional.</i> USB device connection.
Dual Link DVI-D Port	<i>Optional.</i> Digital monitor connection.
Serial Port	<i>Optional.</i> Serial device connection.
HDMI Port	<i>Optional.</i> HDMI video connection.
USB Ports (2)	<i>Optional.</i> USB device connection.
Network Port	Network connection.

Model 650 Rear Panel Ports and Connectors

The following figure illustrates the Barracuda Message Archiver model 650 rear panel ports and connectors:




The following table describes the Barracuda Message Archiver model 650 rear panel ports and connectors:

Port/Connector Name	Details
Power Supply	Power supply input.
Power Switch	Power switch.
Serial Port	<i>Optional.</i> Serial device connection.
IPMI Port	Intelligent Platform Management Interface (IPMI) port for device management over the network.
USB Ports (4)	<i>Optional.</i> USB device connection.
Network Ports (2)	Network connection.
VGA Port	<i>Recommended.</i> Video graphics array (VGA) monitor connection.

Barracuda Message Archiver Model 850 and 950

Front Panel Components

The following figure illustrates the Barracuda Message Archiver models 850 and 950 power and disk activity indicator lights:




The following table describes the Barracuda Message Archiver front panel indicator lights for models 850 and 950.

Component Name	Description
Power Supply/Internal Fan	Power supply and internal fan issue indicators: <ul style="list-style-type: none"> • Continuously on and red – An overheat condition has occurred; this may be caused by cable congestion. • Blinking red (1Hz) – Fan failure, check for an inoperative fan. • Blinking red (0.25Hz) – Power failure; check for non-operational power supply. • Solid blue – Local UID has been activated; use this function to locate the server in a rack-mount environment. • Blining blue (300 mSEC) – Remote UID is on; initiate this function from a remote location to identify the appliance.
Network Activity (2)	Blinks green to indicate network activity.
Disk Light	Displays a solid orange light and blinks during disk activity.
Power Light	Displays a solid green light when the system is powered on.
Reset Button	Push for 5 seconds to reset the appliance.
Power Button	Push to power on the appliance, and tap to safely reboot the appliance.

Model 850 Rear Panel Ports and Connectors

The following figure illustrates the Barracuda Message Archiver model 850 rear panel ports and connectors:




The following table describes the Barracuda Message Archiver model 850 rear panel ports and connectors:

Port/Connector Name	Details
Power Supply (2)	Power supply input. ⁽¹⁾
Power Indicator Lights	Displays based on power supply health: <ul style="list-style-type: none"> • Solid green light - System is powered on and the power supply is healthy • Solid orange/amber light - Power supply is degraded* • No light - System is not powered on or a power supply unit (PSU) has failed
Serial Port	<i>Optional.</i> Serial device connection.
IPMI Port	IPMI port for device management over the network.
USB Ports (4)	<i>Optional.</i> USB device connection.
Network Ports (2)	Network connection.
VGA Port	<i>Recommended.</i> Video graphics array (VGA) monitor connection.
Note: ⁽¹⁾ The power supply may be degraded when, for example, one of the PSUs is not functioning. Push Reset ; if this does not resolve the issue you may need to replace a PSU. Contact Barracuda Networks Technical Support for additional troubleshooting.	

Model 950 Rear Panel Ports and Connectors

The following figure illustrates the Barracuda Message Archiver model 950 rear panel ports and connectors:



The following table describes the Barracuda Message Archiver model 950 rear panel ports and connectors:


Port/Connector Name	Details
---------------------	---------

Power Supply (2)	Power supply input. ⁽¹⁾
Power Indicator Lights	Displays based on power supply health: <ul style="list-style-type: none"> • Solid green light - System is powered on and the power supply is healthy • Solid orange/amber light - Power supply is degraded* • No light - System is not powered on or a power supply unit (PSU) has failed
Serial Port	<i>Optional.</i> Serial device connection.
IPMI Port	IPMI port for device management over the network.
USB Ports (4)	<i>Optional.</i> USB device connection.
Network Ports (2)	Network connection.
VGA Port	<i>Recommended.</i> Video graphics array (VGA) monitor connection.
Note: ⁽¹⁾ The power supply may be degraded when, for example, one of the PSUs is not functioning. Push Reset ; if this does not resolve the issue you may need to replace a PSU. Contact Barracuda Networks Technical Support for additional troubleshooting.	

Barracuda Message Archiver Model 1050

Front Panel Components

The following figure illustrates the Barracuda Message Archiver model 1050 power and disk activity indicator lights:




The following table describes the front panel indicator lights for model 1050.

Component Name	Description
Power Button	Push to power on the appliance, and tap to safely reboot the appliance.
Reset Button	Push for 5 seconds to reset the appliance.
Power Light	Displays a solid green light when the system is powered on.
Disk Light	Displays a solid orange light and blinks during disk activity.
Network Activity (2)	Blinks green to indicate network activity.
Power Supply/Internal Fan Indicators	Power supply and internal fan issue indicators: <ul style="list-style-type: none"> • Continuously on and red – An overheat condition has occurred; this may be caused by cable congestion. • Blinking red (1Hz) – Fan failure, check for an inoperative fan. • Blinking red (0.25Hz) – Power failure; check for non-operational power supply. • Solid blue – Local UID has been activated; use this function to locate the server in a rack-mount environment. • Blining blue (300 mSEC) – Remote UID is on; initiate this function from a remote location to identify the appliance.

Rear Panel Ports and Connectors

The following figure illustrates the Barracuda Message Archiver model 1050 rear panel ports and connectors:



The following table describes the Barracuda Message Archiver model 1050 rear panel ports and connectors:

Port/Connector Name	Details
Power Supply (2)	Power supply input. ⁽¹⁾
Power Indicator Lights	Displays based on power supply health: <ul style="list-style-type: none"> • Solid green light - System is powered on and the power supply is healthy • Solid orange/amber light - Power supply is degraded* • No light - System is not powered on or a power supply unit (PSU) has failed
Serial Port	<i>Optional.</i> Serial device connection.
IPMI Port	IPMI port for device management over the network.
USB Ports (4)	<i>Optional.</i> USB device connection.
Network Ports (2)	Network connection.
VGA Port	<i>Recommended.</i> Video graphics array (VGA) monitor connection.

Note: ⁽¹⁾The power supply may be degraded when, for example, one of the PSUs is not functioning. Push **Reset**; if this does not resolve the issue you may need to replace a PSU. Contact [Barracuda Networks Technical Support](#) for additional troubleshooting.

Figures

1. 150_front_panel_Sept2017.png
2. 150_rear_panel_diagram_Sept2017.png
3. 350_450_rear_panel_diagram_Sept2017.png
4. 650_rear_panel.png
5. 2U_3U_front_panel_indicators_Sept2017.png
6. 850_rear_panel.png
7. 950_rear_panel.png
8. 4U_front_panel_indicators_Sep2017.png
9. 1050_4U_rear_panel.png

© Barracuda Networks Inc., 2021 The information contained within this document is confidential and proprietary to Barracuda Networks Inc. No portion of this document may be copied, distributed, publicized or used for other than internal documentary purposes without the written consent of an official representative of Barracuda Networks Inc. All specifications are subject to change without notice. Barracuda Networks Inc. assumes no responsibility for any inaccuracies in this document. Barracuda Networks Inc. reserves the right to change, modify, transfer, or otherwise revise this publication without notice.