

How to Activate and License a Standalone Hardware Barracuda NG Appliance

<https://campus.barracuda.com/doc/41115845/>

To automatically download and install the license on your Barracuda NG hardware unit, connect to the system using Barracuda NG Admin. NG Admin transmits the serial number of your unit to the Barracuda Licensing service and initiates the activation process. After completing the customer information form and accepting the EULA, your license is activated and automatically downloaded and installed on your unit.

Before you Begin

NG Admin must be able to connect to the Barracuda Licensing Servers on the Internet.

Automatically Download and Activate your Licenses

1. Log into the Barracuda NG Firewall using NG Admin.

Default User: root

Default Password: ngf1r3wall

2. (optional) Complete the Getting Started Wizard. For more information, see [Getting Started](#).
3. The activation process is initiated automatically after 30 seconds. You can also start the process manually by clicking on the blue arrow. After downloading the licenses, a browser window with the activation form opens.
4. Fill out the customer form, accept the License Agreement, and then click **Activate**.
 - After the activation process successfully completes, you will receive a notification email from Barracuda Networks Customer Services.
 - If you are using a high availability setup, your secondary Barracuda NG unit waits for the license to be activated and then receives the license from the primary unit.

Uptime:	4 Days and 23:08:12	Firmware Version:	GWAY-5.4.3-182
System Time:	Mon Jun 2 11:11:58 2014	Appliance Model:	
Box:	10.0.91.70 - doc	Serial Number:	010101
License State:	Normal box operation	Number of CPUs:	4
Activation State:	Current	Architecture:	64 bit
		Admin Sessions:	6

Your Barracuda NG hardware appliance is now licensed and activated. Check **Control > Licenses** to see which licenses are installed on your unit.

Normal box operation

ACTIVE LICENSES Enter new License Token Edit Licenses

Name/Module	License	Expires	HostID	Status
base-bnrf50	283013-BN-VF50-1311012525	02.01.2030 01:00:00	MAC-00:50:56:11:11:11	Valid-Host-ID
add-bnrf50-e	283013-BN-VF50-EnergizeUpdate-1311012532	02.01.2030 01:00:00	MAC-00:50:56:11:11:11	Valid-Host-ID
add-bnrf50-v	283013-BN-VF50-VPN-1311012527	02.01.2030 01:00:00	MAC-00:50:56:11:11:11	Valid-Host-ID
add-bnrf50-w	283013-BN-VF50-WebSecurity-1311012528	27.07.2016 02:00:00	MAC-00:50:56:11:11:11	Valid-Host-ID

License Values

- License: Barracuda
- License-Virtual: True
- License-Model: VF50
- Capacity: 50
- Web-Security: 50
- SSLVPNAC: licensed
- Demo Mode: no
- Export Mode: no
- CC managed: no
- Platform:
- Product: vf50
- Configured Appliance: VF50
- Detected Appliance: VM
- Serial Number:
- Flash based: no
- Statistics: yes
- Licensed Tunnels: unlimited

Figures

1. license_hw01.png
2. license_hw02.png

© Barracuda Networks Inc., 2020 The information contained within this document is confidential and proprietary to Barracuda Networks Inc. No portion of this document may be copied, distributed, publicized or used for other than internal documentary purposes without the written consent of an official representative of Barracuda Networks Inc. All specifications are subject to change without notice. Barracuda Networks Inc. assumes no responsibility for any inaccuracies in this document. Barracuda Networks Inc. reserves the right to change, modify, transfer, or otherwise revise this publication without notice.