
How to Configure a Wi-Fi Network

<https://campus.barracuda.com/doc/48203120/>

For NextGen Firewall models equipped with WiFi, the firewall can act as an access point by introducing up to three WiFi services.

Step 1. Enable the Wi-Fi Network

1. Go to **CONFIGURATION > Configuration Tree > Box > Network**.
2. In the left menu, expand **Configuration** and select **Wi-Fi**.
3. Select **yes** from the **Wi-Fi Enabled** list.
4. From the **Location** list, select your location.
5. From the **Channel** list, select the desired channel.
6. From the **Transmission Power** list, select the applicable transmission power level.
Do not select the highest transmission power level for the Barracuda NextGen Firewall F-Series F101 unless it is located in a cool and well ventilated location.
7. Click **Send Changes** and **Activate**.

Step 2. Configure the Wi-Fi Service Properties

1. Go to **CONFIGURATION > Configuration Tree > Box > Virtual Servers > your virtual server > Assigned Services > Wi-Fi > Service Properties**.
2. Click **Lock**.
3. In the **Service Definition** section, select yes from the **Enable Service** list.
4. In the **Description** field, enter an optional description of the Wi-Fi service.
5. Click **Send Changes** and **Activate**.

Step 3. Configure a Direct Attached Route for the Wi-Fi Network

If your LAN and Wi-Fi connections are in two different networks, configure a default route for the Wi-Fi LAN by completing the following steps:

1. Go to **CONFIGURATION > Configuration Tree > Box > Network**.
2. In the left menu, expand **Configuration** and click **Routing**.
3. Click **Lock**.
4. In the **Main Routing Table** section, add a new entry to the **Routes** table.
5. Enter a **Name** for the route. The **Routes** configuration window opens.
6. In the **Target Network Address** field, enter the WiFi network address. E.g., 192.168.1.0/24

7. From the **Route Type** list, select **directly attached network**.
8. From the **Interface Name** list, select the interface the network is attached to. E.g., **ath0**
9. Click **OK**.
10. Click **Send Changes** and **Activate**.

Step 4. Add an IP address from the WiFi network to the Virtual Server IP Addresses

1. Go to **CONFIGURATION > Configuration Tree > Box > Virtual Servers > your virtual server > Server Properties**.
2. Click **Lock**.
3. Click **+** to add an entry to the **Additional IP** table. the **Additional IP** window opens.
4. Configure the IP address:
 - **Additional IP** - Enter an IP address from the WiFi network. E.g., 192.168.1.1
 - **Reply to Ping** - Select **yes**.
5. Click **OK**.
6. Click **Send Changes** and **Activate**.

Step 5. Activate the Network Configuration

1. Go to **CONTROL > Box**.
2. In the left menu, expand **Network** and click **Activate new network configuration**.
3. When the activation window opens, select **Failsafe** as the activation mode.
4. When the **Activation Succeeded** window opens, click **OK**.

Step 6. Configure the Wi-Fi Security Settings

1. Go to **CONFIGURATION > Configuration Tree > Box > Virtual Servers > your virtual server > Assigned Services > Wi-Fi > Wi-Fi AP Configuration**.
2. Click **Lock**.
3. In the **Network Name (SSID)** field, enter the network name.
4. In the **Preshared Key (PSK)** table, click **+** to add a new entry. The **Preshared Key (PSK) Combination** window opens.
5. In the **New** field, enter a new password.
6. In the **Confirm** field, re-enter the new password.
7. Click **OK**.
8. Click **Send Changes** and **Activate**.

After completing the configuration, go to the **CONTROL > Network** page and verify that the Wi-Fi interface is available. If the interface is available, a green square is displayed next to its name.

Troubleshooting

If the Wi-Fi interface is not available (indicated by a red square),

1. Verify that you completed all the configuration steps.
2. Make sure that the system is up-to-date with firmware patches.

If the Wi-Fi interface is still not available after completing these two steps, reboot the system:

1. Open the **CONTROL > Box** page.
2. In the left menu, expand **Operating System** and click **Reboot Box**.
3. After rebooting the system, go to the **CONTROL > Server** page and check the **Server Status** table to make sure that the service is running.
4. To restart the service, right-click it in the table and click **Restart Service**.

If Wi-Fi still is not enabled, contact [Barracuda Networks Technical Support](#).

© Barracuda Networks Inc., 2020 The information contained within this document is confidential and proprietary to Barracuda Networks Inc. No portion of this document may be copied, distributed, publicized or used for other than internal documentary purposes without the written consent of an official representative of Barracuda Networks Inc. All specifications are subject to change without notice. Barracuda Networks Inc. assumes no responsibility for any inaccuracies in this document. Barracuda Networks Inc. reserves the right to change, modify, transfer, or otherwise revise this publication without notice.