

F800 Revision A

<https://campus.barracuda.com/doc/73696415/>



Warranty and Safety Instructions

Opening your Barracuda Networks appliance or removing its warranty label unless instructed to do so by Barracuda Networks support will void your warranty and hardware support.

[Barracuda Networks Appliance Safety Instructions](#)

Always use the power supply shipped with the appliance.

Default Port Configuration Revision A

The standard version of the F800 appliance has the first port bracket equipped with eight GBE RJ45 copper ports. The second port bracket is covered with a blind plug. Barracuda Networks offers [optional network modules](#) for this appliance.

OS Notation	Speed	Management Port
portA1	10/100/1000 MBit RJ45	X
portA2	10/100/1000 MBit RJ45	
portA3	10/100/1000 MBit RJ45	
portA4	10/100/1000 MBit RJ45	
portA5	10/100/1000 MBit RJ45	
portA6	10/100/1000 MBit RJ45	
portA7	10/100/1000 MBit RJ45	
port A8	10/100/1000 MBit RJ45	

Hardware Specifications

Component	Specifications
-----------	----------------

CPU	Intel Quad Core
Memory	8 GB
HDD (formatted)	1 x 500 GB
Flash Disk	128 MB
LCD Module	2 x 20 characters
USB	2x USB 2.0
Form Factor	1U rack mount
Dimensions (W/D/H)	52.0 x 43.0 x 4.4 cm 20.5 x 17.0 x 1.7 in
Net Weight	28.6 lbs / 13 kg
Power Supply	Single, internal
Power Supply Input Voltage	100 - 240 V, AC
Power Supply Voltage	47 Hz - 63 Hz
Power Supply Watts	300 W
Storage Temperature	-20 °C - +70 °C
Operation Temperature	0 °C - 40 °C
Relative Humidity	5% - 95%, non-condensing
Certifications	CE, FCC, ROHS

The hardware specifications list was valid at the time this manual was published. The listed components are subject to change at any time, as Barracuda Networks may change hardware components due to technological advancements. Therefore, the list may not reflect the current hardware configuration of the Barracuda Networks NextGen Firewall F-Series or NextGen Control Center appliance it was delivered with.

Status LED

Your appliance is equipped with a variety of LEDs. One of them is the Status LED. It is labeled either with a heart symbol or the term Status. It indicates the appliance's operational state by changing colors between green, orange and red, and by changing between blinking and steady glowing. The table below shows the different meanings of the different glowing states.

Color	Glowing State	Meaning: Installation	Meaning: Normal Operation or Active Recovery Technology (ART) Operation
-------	---------------	-----------------------	---

Off	Off	Appliance is powered off or installation has not initialized far enough for LED control when installation is started.	Appliance is powered off.
Green	Blinking	Normal installation.	Appliance is either booting, shutting down, or performing a system update.
Green	Steady	Installation was completed successfully. Appliance is halted for reboot or installation was not yet initialized far enough for LED control.	Barracuda NextGen Firewall is up and running.
Red	Blinking	Error during installation.	An error has occurred, preventing the Barracuda NextGen Firewall from entering the up state. If no orange light available: appliance is in ART mode.
Red	Steady	-	Appliance is halted and may be disconnected.
Orange	Blinking	-	-
Orange	Steady	-	Appliance is in ART mode.

Not all appliances support orange and/or red LED colors. Depending on the appliance type, the status LED might be on by default, and it might take some time during boot and installation to start either blinking or changing the color. Furthermore, the status LED might blink at different frequencies.

Serial Console Port

In order to establish a console connection to the appliance using a serial cable (Revision A: DB9, Revision B: RJ45), you need to configure the serial port on the terminal using the following parameters:

Parameter	Value
Baud	19200
Bits	8
Stop bit	1
Parity	None
Handshake	None

LCD Display

Navigating

This security appliance features a key pad with four keys and an LCD panel on the left side of the front panel. These may be used to obtain certain information and to perform certain commands directly on the appliance.

Key	Command
Left	Navigates back or acts like an Escape key while working in the LCD menu.
Up	Navigates up or increases a value.
Down	Navigates down or decreases a value.
Right	Navigates forwards or acts like an Enter key for confirming a configuration step.

LCD Display Menu

You may use the LCD display and the keypad to access certain appliance features. Use the up and down keys to navigate through the items of the main menu.

The LCD menu features the following items from top to bottom:

Menu	Meaning
Appliance type, OS version, and release number	This is the default display.
IP address and subnet mask	Shows the configured IP address and subnet mask of the appliance.
Time and date	Shows time and date currently configured on the appliance.
Uptime of Barracuda OS	The uptime in days, hours, and minutes.
Serial number of the appliance	Unique identifier for the appliance.
Shutdown menu	Enables you to shut down the appliance.
Reboot menu	Enables you to reboot the appliance.
Menu to change the management IP address	Configure the IP address for the management port.

Menu to boot into ART during the next reboot	Enables you to set a flag that will cause the appliance to boot into ART the next time it is rebooted. Once set, this flag cannot be deleted through the menu. When rebooted, the appliance will not start Barracuda OS, but ART instead. You may connect to the appliance by using the serial console or by SSH. A Control Center-managed box running in ART mode cannot be managed through the CC, although it will build a connection to the CC signalling its presence.
--	--

Rack Mounting

For information on how to mount your appliance, see [Rack Installation for Barracuda CloudGen Firewall F800 Revision C and F900 Revision A,B](#)

Figures

1. F800-A-Front.png

© Barracuda Networks Inc., 2021 The information contained within this document is confidential and proprietary to Barracuda Networks Inc. No portion of this document may be copied, distributed, publicized or used for other than internal documentary purposes without the written consent of an official representative of Barracuda Networks Inc. All specifications are subject to change without notice. Barracuda Networks Inc. assumes no responsibility for any inaccuracies in this document. Barracuda Networks Inc. reserves the right to change, modify, transfer, or otherwise revise this publication without notice.