


## How to Configure a Firewall for Zero Touch Deployment

<https://campus.barracuda.com/doc/79463166/>

To deploy a firewall via Zero Touch Deployment (ZTD), the Control Center must be configured to sync with the Zero Touch Deployment service. Create the firewall configuration and push the basic configuration to the Zero Touch Deployment service. It is always recommended to order the firewall with the Zero Touch option. However, you can manually claim a firewall that was ordered without the Zero Touch option.

- **Orders placed with ZTD option** – The firewall is automatically assigned to the Control Center. It cannot be claimed manually via the linking code to avoid having the wrong customer claim the firewall.
- **Orders placed without ZTD option** – The firewall is not associated with a Control Center. Manually claim the firewall on the Control Center or in the Zero Touch Deployment service web interface using the serial number and linking code supplied in the order confirmation email from Barracuda Customer Services. Firewalls claimed by Control Center can no longer be claimed by another Control Center using the same BCC account to connect to the ZTD service.



### Before You Begin

- Verify that the hardware firewall model is supported for Zero Touch Deployment.
- Verify that the appliance was ordered with the Zero Touch Deployment option, and that you received the order confirmation email with the serial number and linking code.
- Verify that the Control Center and the remote firewalls can


access **ztd.barracudanetworks.com**.

Zero Touch Deployment does not support multi-factor authentication. When deploying a firewall via ZTD, multi-factor authentication must be turned off for the user associated with the login- or Barracuda Cloud Control account.

## Step 1. Configure Zero Touch Deployment Settings

Configure the Control Center to connect to the ZTD portal.


1. Log into the Control Center.
2. Go to **CONFIGURATION > Configuration Tree > Multi-Range > CC Parameters**.
3. Click **Lock**.
4. In the left menu, click **Zero Touch Setup**.
5. Configure the **Zero Touch Deployment Configuration**:
  - **ZTD Service Server** - Enter `https://ztd.barracudanetworks.com`
  - **ZTD Service Port** - Enter 443



Zero Touch Deployment Service Configuration

Zero Touch Deployment Service	<input type="text" value="https://ztd.barracudanetworks.com"/>	
Port	<input type="text" value="443"/>	

6. In the left menu, click **BCC Authentication**.
7. Enter the ZTD portal **Username**.
8. Set the ZTD portal **Password**.



Username	<input type="text" value="mzoller@barracuda.com"/>		
Password	New	<input type="password" value="•••••"/>	
	Confirm	<input type="password" value="•••••"/>	
Strength	<input type="text"/>		

9. Click **Send Changes** and **Activate**.

## Step 2. Create the Firewall Configuration

Prepare the firewall configuration on the Control Center. Verify that the cluster version and the firmware installed on the firewall match.

1. Go to **CONFIGURATION > Configuration Tree > your range > your cluster > Boxes**.
2. Right-click **Boxes** and select either **Create Box Wizard** or **Create Box**.


For more information, see [How to Add a New CloudGen Firewall to the Control Center](#) and [How to](#)

[Configure a Remote Management Tunnel for a CloudGen Firewall.](#)


### Step 3. (Orders without ZTD option) Claim the Firewall

If the firewall was not part of a ZTD order, it can still be associated with the Control Center by manually claiming the appliance. The serial number and linking code required to claim a firewall is included in the invoice email and on the back of the Quick Start Guide included with the firewall. It is not possible to claim an appliance that has already been claimed on a different Control Center or that has been ordered as part of a ZTD order.

1. Go to **CONTROL > Zero Touch Deployment**.
2. Right-click on the firewall and select **Claim Appliances for Zero Touch Deployment**. The **Claim Appliance from Zero Touch Deployment** window opens.



3. Enter the **serial number** and **linking code**.




4. Click **OK**.


### Step 4. Push the Basic Configuration

Push the basic configuration for the claimed firewall to the Zero Touch Deployment service.

1. Go to **CONFIGURATION > Configuration Tree > your range > your cluster > Boxes > your firewall**
2. Right-click the firewall and select **Push Configuration to Zero Touch Deployment**. The **Push Configuration to Zero Touch Deployment** window opens.



3. **Select the matcher type** to determine which firewall the basic configuration is assigned to.
  - o **All** - The new firewall connecting to ZTD is selected.
  - o **Local IP/Subnet** - The IP address or network assigned to the DHCP interface of the firewall.
  - o **Public IP/Subnet** - The public IP address, as seen by the ZTD portal.
  - o **Serial Number** - The serial number of the appliance.
4. Depending on the matcher, enter the **matching value**.



5. Click **OK**.

Go to **CONTROL > Zero-Touch Deployment** and verify that the appliance state is **In Progress**.

Appliances and Configurations - Last Update : 17.06.2019 08:45:53													
Type	Range	Cluster	Box	Serial	Status	Product	Model	Last Seen	Remote IP	Matching Type	Matching Value	Matching Value	
Configured Appliance	1	ZTDCluster	ZTD-CGF1	271537	In Progress	BNG	F201	registered	03-03-2017 16:20:47	10.146.125.186	Serial Number	271537	

As soon as the claimed firewall connects to ZTD, the firewall uses the basic configuration to connect to the Control Center. The **ZTD** status is **Completed**.

Appliances and Configurations - Last Update : 17.06.2019 08:45:53													
Type	Range	Cluster	Box	Serial	Status	Product	Model	Last Seen	Remote IP	Matching Type	Matching Value	Matching Value	
Configured Appliance	1	ZTDCluster	ZTD-CGF1	271537	Completed	BNG	F201	03-03-2017 16:20:47	10.146.125.186	Serial Number	271537		

Troubleshooting information can be found in the Zero Touch Deployment service web interface or in the ZTD log file `Box/Config/daemon.log` and `Box/Config/ztd.log`

When pushing configurations from a CC to the ZTD service, the version number of the pushed configuration can even be lower than the firewall's firmware version as long as the version of the pushed configuration supports ZTD. However, this does not affect the need to keep a firewall's version in sync with existent range or cluster versions.

## Figures

1. ztd\_portal\_push.png
2. ztd01.png
3. ztd01a.png
4. ztd02.png
5. ztd04.png
6. ztd05.png
7. ztd06.png
8. ztd07.png
9. ztd08.png

© Barracuda Networks Inc., 2020 The information contained within this document is confidential and proprietary to Barracuda Networks Inc. No portion of this document may be copied, distributed, publicized or used for other than internal documentary purposes without the written consent of an official representative of Barracuda Networks Inc. All specifications are subject to change without notice. Barracuda Networks Inc. assumes no responsibility for any inaccuracies in this document. Barracuda Networks Inc. reserves the right to change, modify, transfer, or otherwise revise this publication without notice.