Aastra Phones

https://campus.barracuda.com/doc/39823367/

This article refers to Barracuda Phone System and Aastra® phones.

Provision the Phone

Use the following steps to configure Aastra phones using the Aastra web server:

1. In a web browser window, enter `http://x.x.x.x` where `x.x.x.x` is the Aastra phone IP Address.
2. The web interface displays. Enter your login credentials, and click **OK**.
3. Under **Advanced Settings**, click **Configuration Server**.
4. Select **TFTP Server**, and enter the Barracuda Phone System IP address in the associated field.
5. Select **Save Settings**, and then click **Restart**.
6. Allow the phone to restart; this takes approximately five minutes.
7. After a phone is provisioned by the Barracuda Phone System, its password changes to **2832**.

Reset Factory Defaults

If the phone fails to provision, reset its configuration with the following steps:

1. Press the **Options** button, and press the **Down** arrow until the **Admin Menu** displays onscreen.
2. Press the **Right** arrow, and enter the **Admin** password, and press the **Right** arrow again; the default Admin password is **22222** .
3. Press the **Down** arrow until **Factory Default** displays onscreen.
4. Press the **Right** arrow, and then press the **#** key to confirm.
5. When the screen displays **Reset Phone**, press the **#** key to confirm.
6. Press **#** to restart the phone.

You can now re-provision the phone.