

Hookflash Transfer on Analog Cisco SPA Devices

<https://campus.barracuda.com/doc/41091416/>

This article refers to Barracuda Phone System and Cisco® phones.

The following Cisco SPA analog devices have FXS ports allowing Hookflash Transfer:

- PAP2T
- SPA-3102
- SPA-112
- SPA-122

To Hookflash Transfer from an analog phone follow these steps:

1. With a call on the line, press the flash key or hold down the hookswitch (for about one second).
2. Wait for dial tone, and then dial ***98**.
3. Wait for dial tone again, and then dial the destination number.
4. Hang up when you hear ringing.
5. To return to the original call, instead of performing a transfer, simply Hookflash Transfer back.

© Barracuda Networks Inc., 2020 The information contained within this document is confidential and proprietary to Barracuda Networks Inc. No portion of this document may be copied, distributed, publicized or used for other than internal documentary purposes without the written consent of an official representative of Barracuda Networks Inc. All specifications are subject to change without notice. Barracuda Networks Inc. assumes no responsibility for any inaccuracies in this document. Barracuda Networks Inc. reserves the right to change, modify, transfer, or otherwise revise this publication without notice.