



FSC Wi-Fi Access Point

The Wi-Fi interface can be configured to act as an access point. In Access Point mode, the FSC uses a DHCP server for clients connecting to the Wi-Fi. Depending on the configuration of the zone firewall, Wi-Fi clients can then access either the Internet via the WAN port, or send all traffic through the VPN to the FSAC in your network. A gateway route for the Wi-Fi network is automatically created in Access Point mode. You can also disable the Wi-Fi interface.

Wi-Fi Access Point

Configuration using the Secure Connector Editor

1. Go to **your cluster** > **Cluster Settings** > **Secure Connector Editor**.
2. Click **Lock**.
3. Double-click on the device or template.
4. In the left menu, click **Wi-Fi Settings**.
5. From the **Wi-Fi Mode** drop-down list, select **Access-Point**.
6. Click **+** to add a **SSID**. The **SSID** window opens.
7. Enter a **Name** for the Wi-Fi network, and click **OK**.
8. Enable the **Active** check box.
9. Enter the **SSID**.
10. (optional) Select the **Security Mode**.
11. Enter the **Passphrase**.

| | | |
|---------------------------|----------------------------------------------------------------------|--|
| Active | <input checked="" type="checkbox"/> | |
| SSID | <input type="text" value="SCAWiFi"/> | |
| Security Mode | <input type="text" value="WPA2-PSK"/> | |
| Passphrase | <input type="text" value="supercomplicatedandsecurewifipassphrase"/> | |
| SSID valid for Wi-Fi Mode | <input type="text" value="Access-Point"/> | |
| Interface Name | <input type="text" value="WIFI"/> | |

12. Click **OK**.



13. (optional) Select the **Network Mode** and **Wi-Fi Channel**.
14. (optional) Change the Wi-Fi Network: Click **OK** and **Activate**.
 - **IP Address** – Enter the IP Address of the Wi-Fi Interface.
 - **Subnet Mask** – Select the subnet mask.
 - **DHCP Start IP** – Enter the first IP address of the DHCP range.
 - **DHCP End IP** – Enter the last IP address of the DHCP range.
15. Click **OK** and **Activate**.

Configuration Using Web Interface Override

Use the web interface override to temporarily restore connectivity. Correct any misconfigurations on the Control Center beforehand because the configuration on the FSC will be overridden immediately after the configuration lock in the web interface has been released.

1. Log into the web interface.
2. Go to the **CONFIGURATION > Wireless** page.
3. Click **Retrieve Lock**.
4. In the **Wi-Fi CONFIGURATION** section, set **Operating Mode** to **Access Point**.
5. From the **Country** drop-down list, select your country.

The screenshot shows the web interface for configuring wireless settings. At the top, there are navigation tabs: Status, Log, Administration, Network, **Wireless**, DHCP, and VPN. A 'Release Lock' button is in the top right. Below the tabs, the 'Wireless' section is active. The 'WIFI CONFIGURATION' section is highlighted with a blue header and a 'Save Changes' button on the right. The configuration options are:

- Operating Mode: Radio buttons for Off, Client, and **Access Point** (selected).
- Country: A dropdown menu showing 'AUSTRIA'.
- Network Mode: Radio buttons for 802.11b and **802.11g** (selected).

6. Click **Save Changes**.
7. In the **Wi-Fi AP INTERFACE** section, configure the Wi-Fi interface settings:
 - **Automatic Network Assignment** – Set **Auto Mode** to **Enabled**.
 - **Explicit Network Assignment** – Set **Auto Mode** to **Disabled**.
8. (Explicit network assignment only):
 1. Enter the **IP Address** assigned to the Wi-Fi interface. Do not use an IP address that is part of the FSC network.
 2. Select the **Subnet Mask**.
 3. Set **DHCP Server** to **Enabled**.
9. Click **Save Changes**.
10. In the **Wi-Fi SSIDS** section select **Add SSID**. The **Add Wi-Fi SSID** page opens.
11. Configure the wireless network settings:
 - **Mode** – Select **Access Point**.
 - **SSID** – Enter the wireless network identifier.
 - **Security Mode** – Select **WPA-PSK2**, **WPA-PSK** or **None**.
 - **Passphrase (WPA-PSK2, WPA-PSK only)** – Enter the passphrase.



| WIFI SSID | |
|---------------|----------------------------------------------------------------------------------------------------|
| Enabled | <input checked="" type="radio"/> Enabled <input type="radio"/> Disabled |
| Mode | <input type="radio"/> Client <input checked="" type="radio"/> Access Point |
| SSID | <input type="text" value="myidentifier"/> |
| Security Mode | <input type="radio"/> None <input type="radio"/> WPA-PSK <input checked="" type="radio"/> WPA-PSK2 |
| Passphrase | <input type="text" value="test1234567890"/> |

12. Click **Add SSID**.
13. Enter the **Passphrase**.
14. Click **Add SSID**.
15. On the top of the page, click **Activate Configs**.
16. To return to using the configuration stored on the Control Center, click **Release Lock**.

Disable Wi-Fi

Configuration using the Secure Connector Editor

1. Go to **your cluster > Cluster Settings > Secure Connector Editor**.
2. Double-click on the device or template.
3. In the left menu, click **Wi-Fi Settings**.
4. From the **Wi-Fi Mode** dropdown list, select **Off**.
5. (optional) Alternatively, you can also disable individual SSID:
 1. Double-click on the **SSID**.
 2. Disable the **Active** check box.
 3. Click **OK**.
6. Click **OK** and **Activate**.

Configuration Using Web Interface Override

Use the web interface override to temporarily restore connectivity. Correct any misconfigurations on the Control Center beforehand because the configuration on the FSC will be overridden immediately after the configuration lock in the web interface has been released.

1. Log into the web interface.
2. Go to the **CONFIGURATION > Wireless** page.
3. Click **Retrieve Lock**.
4. In the **Wi-Fi CONFIGURATION** section, set **Operating Mode** to **Off**.
5. Click **Save Changes**.
6. On the top of the page, click **Activate Configs**.
7. To return to using the configuration stored on the Control Center, click **Release Lock**.

