



# Administration

Use the web interface to set up and administer your Barracuda Backup appliance.

## Barracuda Cloud Control

Your Barracuda Cloud Control account gives you access to Barracuda Backup, Barracuda Networks services to which you have a subscription, and any devices added through Barracuda Appliance Control. As long as you are logged in as an administrator, you can add users and assign roles. Each user uses their own user name to log in.

**Table 1. Manage Your Account.**

Feature	Details
Select Account Options	<p>Click the <b>Home</b> link in the left pane to perform these account-related tasks:</p> <ul style="list-style-type: none"> <li>• Add, edit and remove users, including setting their privileges and start page. When you add a user you can select the services that the user is able to access.</li> <li>• View audit logs.</li> <li>• Update contact and billing information for your Barracuda Cloud Control account.</li> <li>• View invoices.</li> <li>• Manage services associated with your account.</li> <li>• Configure account security and authentication.</li> </ul> <p>Click <b>Backup</b> in the left pane to go to the Barracuda Backup web interface.</p>
Community	<p>Click <b>Community</b> at the top right of the web interface to access product forums and add your own feedback. Use forums to discuss and view feature requests.</p>
Your Account Profile	<p>Click <b>My Profile</b> to perform the following tasks:</p> <ul style="list-style-type: none"> <li>• Set language preference</li> <li>• Set up multi-factor authentication</li> <li>• Set the time zone for your user account</li> </ul>
Support	<p>Click <b>Support</b> at the top right of the web interface to perform the following tasks:</p> <ul style="list-style-type: none"> <li>• Search Barracuda Networks Knowledgebase solutions</li> <li>• Access the Barracuda Networks Campus</li> <li>• Contact Barracuda Networks Technical Support</li> <li>• Access existing support cases, or open a new case</li> <li>• Manage your Barracuda Backup Server serial numbers</li> </ul>

## Users

Administer user access to the Barracuda Backup from the **Admin > Users** page. Click **Add & Remove Users** to add or remove users, or click **Edit** to the right of the user to modify the user's access rights. You can specify the following user options, all of which are specific to Barracuda Backup:

- Receive emails with backup reports, error condition alerts, or Barracuda Backup Server software update notices.
- Restrict access to the Barracuda Backup web interface to one or more IP addresses.
- Designate the user role.

Use the following steps to add Barracuda Backup entitlements when you add a user to your Barracuda Cloud Control account.

Alternatively, if you are already logged in to Barracuda Backup, click **Admin > Users** and complete these steps.

1. Log in to Barracuda Cloud Control as the administrator, click **Home** in the left pane, and go to the **Admin > Users** page.



2. Click **Add User**; the new **User Details** displays.
3. Enter the new user's first and last name in the **Name** field, and enter their **Email** address; the user email address will serve as their username.
4. Select the **Starting Page** for this user upon log in from the following options:
  - **Default**
  - **Community/Forum**
  - **Account**
  - **Support**
5. If you are using **Multi-Factor Authentication**, complete this section.
6. In the **Privileges** section, select from the following options:
  1. **User Management** - Specify whether the user can add, remove, and edit users.
  2. **Billing Administration** - Specify whether the user can update billing information for this account.
7. In the **Product Entitlements** section, click **Backup (Admin)**.
8. Click **Save User** at the top of the page to add the user to Barracuda Backup; an email is then sent to the user prompting them to set their password.
9. Click on the username in the **Users** list; the **User Details** section displays in the right pane. In the **Product Entitlements** section under **Backup (Admin)**, click **Configure Permissions**.
10. In the configuration page, configure **Email Notifications**:
  - **Backup Summary Reports** - When selected, a summary report is sent to this user for each appliance daily.
  - **Backup Detailed Reports** - When selected, a detailed report each time a backup job completes, including a list of all backed up items.
  - **Alerts** - When selected, an alert is sent to this user if an error occurs during a backup job or if a Barracuda Backup appliance goes offline.
  - **Notices** - When selected, a notice is sent to this user when the Barracuda Backup appliance software is updated.
11. If you have multiple appliances on an account, you can selectively limit visibility. To restrict the IP address that this user is allowed to log in from:
  1. In the **IP login restrictions** field, enter an IP block in single 192.168.1.100 notation, CIDR net block 192.168.1.0/24 notation or a range in 192.168.0.0-192.168.0.128 notation to specify the IP addresses from which this user is allowed to log into Barracuda Backup.
  2. Separate multiple IP blocks or ranges with a comma.
12. From the **User role** drop-down menu, select permissions for this user:
  1. **Account Administrator** - User has full access to all Barracuda Backup appliances within the account.
  2. **Barracuda Backup Appliance Administrator** - User has full access to all selected Barracuda Backup appliances; user does not have edit or view user accounts access. When selected, the **Grant access to** section displays:
    - **Select All Backup Appliances** -When selected, user has full access to all Barracuda Backup appliances within the account. When cleared, a list of all connected Barracuda Backup appliances displays. Turn on the Barracuda Backup appliances to which this user is to have access.
  3. **Operators** - User access is limited to viewing statistics and modifying backup configuration for selected Barracuda Backup appliances. Operators cannot restore data or edit user accounts.
    - **Select All Backup Appliances** - When selected, user has *Operator* access privileges to all Barracuda Backup appliances within the account. When cleared, a list of all connected Barracuda Backup appliances displays. Turn on the Barracuda Backup appliances to which this user is to have *Operator* access.
  4. **Helpdesk** - User access is limited to the **Dashboard** page, the restore browser and restore reports on Barracuda Backup Appliances. Helpdesk users can restore data and stop running restores.
    - **Select All Backup Appliances** - When selected, user has *Help Desk* access privileges to



all Barracuda Backup appliances within the account. When cleared, a list of all connected Barracuda Backup appliances displays. Turn on the Barracuda Backup appliances to which this user is to have *Helpdesk* access.

5. **Status** - User access is limited to viewing the **Dashboard** page for Barracuda Backup appliances to which they have access.

- **Select All Backup Appliances** - When selected, user has *Status* access privileges to all Barracuda Backup appliances within the account. When cleared, a list of all connected Barracuda Backup appliances displays. Turn on the Barracuda Backup appliances to which this user is to have *Status* access.

Note that in firmware version 6.4, the **Status** page has been renamed to **Dashboard** in the appliance web interface.

- The multi-appliance dashboard displays irrespective of the firmware version running on the appliances.
- The single appliance dashboard displays on appliances upgraded to firmware version 6.4; older firmware versions continue to display the existing **Status** page.

13. Click **Save** at the top of the page to save the Backup configuration settings for the selected user.

## Email Notifications

Specify the type of email notification for each user on the account, or users not associated with your account (non-users):

- **Backup Summary Reports** - Sends a daily report for each appliance, including information about the last run of each schedule the previous day, is sent
- **Backup Detailed Reports** - Sends a detailed report each time a backup job completes, including a list of all items backed up
- **Alerts** - Sends a notification for conditions such as:
  - A Barracuda Backup appliance is offline or has come online
  - A Barracuda Backup appliance has not been able to communicate with a Barracuda replication target, that is, another Barracuda Backup appliance or Barracuda Cloud Storage (check for Internet problems)
  - A Barracuda Backup appliance, such as a RAID volume or HD hardware, fails
  - An error has occurred in a backup
  - An error situation returned to normal and no (further) action is required
  - You have reached the limit on your Barracuda Cloud Storage subscription plan size
  - A backup job has exceeded 24 hours
- **Notices** - Sends a notification when the your Barracuda Backup appliance software is updated

To specify email notifications for a *user on the account*:

1. Go to the **Admin > Users** page, and click **Edit** to the right of the user name.
2. Select the desired notifications in the **Email notifications** section, and click **Save**.

To specify email notifications for *users not associated with your account* (non-users such as your reseller):

1. Go to the **Admin > Email Notifications** page, and enter an address in the **Email Address** field.
2. Select the notifications you want the user to receive, and click **Add**. The email address is added to the **Recipients** table.

If a backup job exceeds 24 hours, and you have configured **Alerts** on the **Admin > Email Notifications** page, an email notification is sent to the Barracuda Backup administrator. For example:



To resolve, determine whether:

- There is a large amount of new or changed data; see the [Dashboards](#)
- There is a failure in the backup or a reporting failure; see the [Reports Page](#)
- There are issues with replication affecting backup job reporting; see the [Replication Page](#)

## Display Groups

Display groups allow you to manage multiple Barracuda Backup appliances.

Use the following steps to set up display groups:

1. Log in to Barracuda Backup, and go to the **Admin > Display Groups** page.
2. All display groups active on your account display in the **Current Display Groups** section.
3. To add a new display group, enter a name for the group of devices in the **Display Group** field, and then click **Add**. For example, if you want to group all Barracuda Backup by location, you might create groups by geographic location: Engineering - Asia, Engineering - US, Engineering - Europe.
4. The display group name appears in the **Current Display Groups** section.
5. To remove a display group, click **Remove** following the name of the group you want to remove; click **OK** to confirm you want to remove the group.

If you delete a display group that contains devices, those devices are moved to the default group.

Once you create display groups, you can add a Barracuda Backup appliance to the group using the following steps:


1. In the left pane, select the appropriate Barracuda Backup, and go to the **System > Barracuda Backup Appliance Settings** page.
2. In the **Backup Appliance Display Group** section, choose from the **Current Display Group** drop-down list, select the display group name.
3. To add or remove display groups, click **Manage your display groups** to go to the **Admin > Display Groups** page.



4. Click **Save**.

## Important - Resellers

A group that includes multiple customers displays only those devices for the customer selected from the **Current Account** drop-down list. To view all devices for all customers in a group, select **Manage all accounts**:



## Activate Barracuda Backup

Use the **Admin > Activate Barracuda Backup** page to set up your Barracuda Backup appliance. The Barracuda Backup appliance must be linked online before backups can be initiated. See the following sections for details on linking and unlinking a Barracuda Backup appliance:

- [Deploy a Barracuda Backup Appliance](#)
- [Activate a Barracuda Backup Device as a Reseller](#)
- [Activate a New Reseller Device](#)

## Firmware Settings, Notifications, and Updates

Manage firmware updates and view release notes on the **System > Firmware Updates** page.

Use the **System > Firmware Settings** page to select the firmware upgrade policy:

- **Current Installed Version** - Displays the currently installed firmware version
- **Firmware Upgrade Policy** - Select the release stage you want to update to the latest firmware:
  - **Legacy Release** - Access a previously installed version of the firmware; *do not select this option unless directed to do so by [Barracuda Networks Technical Support](#).*
  - **General Release** - The latest generally available version of the firmware available for use on Barracuda Backup.
  - **Early Release** - The newest firmware versions available for early access to Barracuda Backup.
- **Firmware Available** - Specifies the latest firmware version available based on the selected **Upgrade Policy**
- **Upgrade Now** - If a newer version of firmware is available, click **Upgrade Now** to upgrade the firmware
- **View release notes** - Review the release notes to see new features and resolved issues

### Firmware Notification

If a newer version of firmware is available, once you log in to Barracuda Backup, the **Dashboard** page displays a notification banner across the top of the page. Click **Upgrade Now** to immediately begin the firmware upgrade, or click **Dismiss** to hide the banner until the next time you log in to the web interface.

If a backup job is running and you select to upgrade the firmware, the firmware upgrade is queued until the



existing job is completed.

### **Local Control Appliance Firmware Update**

**Local Control is no longer available to new customers but will continue to be supported for existing customers.**

When managing your Barracuda Backup appliance independently of Barracuda Networks Cloud through Local Control, update firmware on the **System > Firmware Settings** page.

To receive firmware update notifications, you must configure an email contact within Barracuda Cloud Control before local control is enabled. This is usually the email account you use when setting up your Barracuda Cloud Control account.

### **Firmware Upgrade Policy**

Verify you are running at least the Legacy Release firmware to ensure compatibility with the Barracuda Backup cloud UI and services such as replication. *Firmware versions older than the latest Legacy Release are not supported.*

Barracuda Backup enables administrators to perform manual upgrades at a time that is convenient, however, Barracuda performs automatic upgrades for Barracuda Backup devices with an active Energize Update subscription if they are running unsupported firmware versions.

### **Energize Updates**

Barracuda Backup requires an Energize Updates subscription for firmware upgrades and Technical Support. Energize Updates are also required to maintain compatibility with the Barracuda Backup Cloud (accessed through [login.barracuda.com](http://login.barracuda.com)). Barracuda Backup performs updates to the cloud to maintain compatibility with the latest legacy, general, or early release firmware versions. Barracuda Backup devices with expired Energize Updates running unsupported firmware versions may experience difficulties using the Barracuda Backup Cloud for management as well as services such as data replication.

This does not apply to the local web-based management interface which is accessible for restores or the Local Control management option.

If your Energize Updates Subscription expires, contact Barracuda Sales to renew your subscriptions.

Note that Barracuda Backup devices managed using Local Control (independent of Barracuda Cloud Control) has access to firmware releases on a delayed schedule.

### **Automatic Firmware Upgrades**

After a major firmware version has completed the rollout phase, Barracuda sends an upgrade notification, providing 30-day's notice before the upgrade takes place. This notification includes information on new features, bug fixes, and end-of-life announcements. You must subscribe to email notices to receive the upgrade notifications.



Devices connected via site-to-site replication must be running matching firmware versions to ensure compatibility.

**Firmware Release Example**

Note that the information listed in the table below may not be current. Go to the **System > Firmware Settings** page in the web interface for the latest firmware availability.

**Table 2. Release Example.**

Major Firmware Version	Latest Maintenance Release	Firmware Upgrade
Version 6.4	6.4.06	Early Release
Version 6.3	6.3.04	General Release
Version 6.2	6.2.04	Legacy Release

**Warning**

Early Release firmware is subject to partial testing. Be aware of the risks before upgrading as firmware versions cannot be reverted.

**Minimum Supported Versions and Historic Releases**

To ensure interoperability with Barracuda Cloud Control, cloud connected Barracuda Backup systems must run the latest firmware version. Download and install the latest available firmware from the **System > Firmware Settings** in the web interface. Additionally:

- You must have an active Energize Update (EU) subscription and be running the latest minimum supported firmware for Barracuda Cloud Control support
- Firmware version must be upgraded to the latest version (legacy, general, or early)
- If firmware version is not maintained, you will lose interoperability with Barracuda Cloud Control; the local restore browser remains accessible for data recovery
- If your Barracuda Backup product no longer has EU, and there is no intention to renew EU, you can restore from the local UI to manage the system independent of Barracuda Cloud Control

**Table 3. Minimum Supported Versions**

Current Major Release	Release Date	Minimum Supported Versions	Legacy Release	General Release	Early Release
-----------------------	--------------	----------------------------	----------------	-----------------	---------------



		<ul style="list-style-type: none"> <li>• Firmware version 6.3</li> <li>• Barracuda Backup Agent 6.3.04 (Windows)</li> <li>• Barracuda Backup Agent 6.3.04 (Linux)</li> <li>• Bare Metal Live CD 6.3.04 (64-bit)</li> <li>• Bare Metal Live CD 6.3.04 (32-bit)</li> </ul>			
6.4	June 6, 2017	<ul style="list-style-type: none"> <li>• GroupWise Trusted Application Key Generator</li> <li>• Backup Export Tool Archive (BET)</li> <li>• Offsite Vaulting</li> <li>• Cloud LiveBoot</li> <li>• Microsoft Windows, Exchange, SQL, and Hyper-V support</li> <li>• VMware support</li> <li>• Site-to-site replication</li> <li>• Supported servers and data types</li> </ul>	6.3.04	6.4.04	6.4.06

**Table 4. Historic Releases**

Version	Release Date	Main Feature(s)	Description
6.4	June 6, 2017	New Dashboard Configure Barracuda Backup Vx to replicate to a physical appliance	<ul style="list-style-type: none"> <li>• The Dashboard has been redesigned for an improved the user experience. When looking at their backup account, customers and resellers will get an aggregate view of all their units. This view changes during Barracuda Backup appliance selection to view specific detail about a selected unit.</li> <li>• You can configure the Barracuda Backup Vx appliance to replicate bi-directionally to another Barracuda Backup Vx or to a Barracuda Backup appliance.</li> <li>• With a Receiver Vx subscription, you can pair a physical appliance and a Barracuda Receiver Vx, one-to-one. Replication from physical appliances to a Receiver Vx is limited to Barracuda Backup models 190 through 690.</li> </ul>
6.3	July 25, 2016	Backup Agent Update and exporting to AWS Storage Gateway-VTL	Boosts initial backup speed and recovery performance by up to 1.5-2x on large files and up to 3x for file server backups with millions of small files with the Barracuda Backup Agent for Windows and Linux.
6.2	August 2015	Backup Summary Report	New Barracuda Backup Summary Report, reporting downloads and improved granularity for scheduling.
6.1	June 2015	Export to tape or disk	Export historical data from Barracuda Backup using the Backup Export Tool.
6.0	September 2014	Local Control	Administer your Barracuda Backup appliance independently of Barracuda Networks' Cloud in a "connectionless" state.
5.4	January 2014	Offsite Vaulting	Extend offsite retention policies for up to twelve monthly and seven yearly revisions.
5.3	September 2013	Microsoft Windows 8/2012 Microsoft Exchange 2013 Microsoft SQL 2012 Microsoft Hyper-V 2012 CSV	Support for Microsoft's latest version of Windows, Exchange, SQL, and Hyper-V.





5.2	May 2013	Cloud LiveBoot	Instantly boot a virtual machine from Barracuda's Cloud.
5.1	February 2013	Restore to Copy Large Items Reporting	Restore data to a Copy account for synchronization and sharing.
5.0	December 2012	LiveBoot	Boot a virtual server instantly from Barracuda's local storage.
4.3	July 2012	Barracuda Backup 1090 64-bit hardware	New high capacity backup appliance and update all systems to the 64-bit architecture.
4.2	April 2012	VMware Support	Agentless VMware backups using the vStorage APIs. Perform a full system restore without installing the operating system.
4.1	November 2011	Bare Metal Recovery	Deprecated support for Windows 2000.
4.0	June 2011	Box-to-box replication	Offsite replication between Barracuda Backup appliances

## Appliance Settings

Use the **System > Barracuda Backup Appliance Settings** page to view or modify the Barracuda Backup appliance details including name, time zone, physical location, and display group:

- **Barracuda Backup Appliance Name** - Name used to identify the currently selected Barracuda Backup appliance in the web interface
- **Backup Appliance Time Zone** - The time zone where the currently selected Barracuda Backup appliance is located
- **Barracuda Backup Appliance Location** - The physical location of the Barracuda Backup appliance including city, state, and country
- **Barracuda Backup Appliance Display Group** - The display group in which the Barracuda Backup appliance resides
  - **Manage your display groups** - Click to add or remove a display group in the **Admin > Display Groups** page
- **Backup Export Tool Settings** - Set up the Backup Export Tool

## Software Downloads

Go to the **System > Software Downloads** page to download tools for use with Barracuda Backup including:

- Barracuda Bare Metal Live CD
- Barracuda Backup Agent (Windows)
- Barracuda Backup Agent (Linux)
- Barracuda Backup Agent (Mac)
- Barracuda GroupWise Trusted Application Key Generator
- Backup Export Tool
- Kroll Ontrack

## Open a Support Tunnel

When Barracuda Technical Support needs to troubleshoot a Barracuda Backup appliance linked through Cloud Control, the technician uses the VPN tunnel between the appliance and the Barracuda Cloud Servers. However, there are some conditions where the VPN tunnel is prevented from connecting. For example, if a Barracuda Backup appliance is linked through Local Control, a support tunnel must be manually opened for remote diagnostics and technical support services over TCP port 22 outbound in contrast with the default VPN connection over port 1194.

### Open a Support Tunnel through the Web Interface

Use the following steps to open a support tunnel through the Barracuda Backup web interface:



1. Log in to <https://login.barracuda.com/>, and select the appliance in the left pane.
2. Go to **System > Troubleshooting**, and click the link to toggle the Support Tunnel **Open**.
3. Once troubleshooting is complete, click the link once again to toggle the Support Tunnel **Closed** to disable the support tunnel.


### Open a Support Tunnel Using the Console

You can use the Console screen to open a support tunnel.


To access and interact with the Console screen, you need a VGA Monitor and USB or PS/2 keyboard.

Use the following steps to open a Support Tunnel using the Console:


1. Connect the VGA monitor and keyboard to the Barracuda Backup appliance.
2. Use the keyboard arrows to highlight **Troubleshooting**, and press either **Enter** or the right arrow key on your keyboard to move the cursor to the **Troubleshooting** menu:



3. Use the arrow keys on your keyboard to move the cursor to **Enable Tunnel** in the **Remote Support** section:



4. Press **Enter** to open a support tunnel. Verify the support tunnel is open:



5. Once troubleshooting is complete, repeat steps 1-4 to **Disable** the support tunnel.

### Open a Support Tunnel from Local Control


The steps in this section apply to both Cloud and Local Control Barracuda Backup appliances; a version of the Local Control interface is available on both.

Use the following steps to log in to the local interface and open a support tunnel for remote diagnostics and technical support services over TCP port 22 outbound:

Administration




1. In a browser window, enter the Barracuda Backup appliance IP address.
2. Log in using your Barracuda Cloud Control credentials.
3. Go to the **System > Device Information** page, and in the **Server Actions** section, click **Open Support Tunnel**:



4. The button changes to **Close Support Tunnel**, and a message displays indicating that the tunnel is open.
5. Once troubleshooting is complete, click **Close Support Tunnel**.

### Shut Down a Barracuda Backup Appliance

You can remotely reboot or shut down a Barracuda Backup appliance by logging in to its local web interface. Type the Barracuda Backup IP address in a web browser, log in using your Barracuda Networks account, and go to the **System > Device Information** page:



You can also perform a safe shutdown of a Barracuda Backup appliance by pressing the **POWER** button on the front of the device. This issues a shutdown command to all system and service processes before the device powers down.



**Caution**

Do not push the **POWER** button for more than a couple of seconds. Holding it for five seconds or longer causes an immediate hard shutdown. This interrupts running processes and the Barracuda Backup appliance powers off before unmounting the file system.


**Wipe a Barracuda Backup Appliance**

Wiping a Barracuda Backup Server unlinks it from your account and puts all data and configuration information into a queue to be purged from Barracuda Cloud Storage. The wipe feature also deletes the contents of the local databases on the Barracuda Backup appliance, moves the binary data on the Barracuda Backup appliance into a temporary storage location on the system, and then shuts it down. The next time the Barracuda Backup appliance is booted, the binary data that has been moved is deleted.


In order for the wipe process to succeed, the Barracuda Backup appliance must first be connected to the Internet; verify the appliance has internet connectivity before proceeding.

Use the following steps to wipe a Barracuda Backup Server to unilink it from your account:

1. Enter the Barracuda Backup IP address to log in to the *local web interface*.
2. Go to the **System > Device Information** page, and in the **Server Actions** section, click **Wipe Barracuda Backup Appliance**:



3. The message **Wipe Started Successfully** displays in the web interface; a warning message displays:



4. Click **OK** to complete the unlinking process. Once the Barracuda Backup appliance is unlinked from the account, the **Backup Server Wipe Successful** page displays, including the Serial Number and Linking Code.



5. Make note of the serial number and linking code. You can now link the Barracuda Backup appliance to a new account. For details, see [Administration for Resellers](#).

