

## How to Prepare External USB Storage for Log File Storage

<https://campus.barracuda.com/doc/79463287/>

You must prepare the USB storage device to be able to use it when cycling your log files. During initialization, the USB device is wiped, and the device label is changed. Only prepared USB storage devices can be used. If multiple prepared USB storage devices are connected, the first device in the list is mounted and used.

### Limitations and Compatibility

Use USB 2.0 compatible external USB storage devices with a dedicated power supply. This feature has been tested and is known to work with the following external USB storage devices:

- Western Digital, WD Elements 4 TB, WDBWLG0040HBK
- Maxtor, D3 Station 4 TB, HX-D401TDB/GM

### Before You Begin

- Connect the USB storage device to a free USB port on your firewall.
- To avoid the SSH sessions from timing out when formatting large external storage devices, go to **Infrastructure Services > Control**, and in the **Administrative Sessions**, set **Console Max Idle** to 0 for the duration of the configuration. Reset the settings to 15 after external log storage is enabled.



The screenshot shows two configuration sections. The first section, 'Auto Logout Setup', contains two input fields: 'Firewall Admin Max. Idle [m]' with the value '60' and 'Console Max. Idle [m]' with the value '0'. The second section, 'Session Password Setup', contains a dropdown menu for 'Disable Session Passwords' set to 'no'.

### Step 1. Prepare USB Storage

1. Log in to your firewall or to the box level of the Control Center with SSH.
2. Enter `prepare_cudastorage`.

```
[root@F101:/mnt/cudastorage]# prepare_cudastorage
Searching for removable disks to use as external log file storage...[ DONE ]
```

```
Detected the following removable disks:
```

```
0) /dev/sdb
```

```
Enter the number matching the USB storage device [0 or q for quit]
```

```
0
```

### 3. Enter the number for the device you want to prepare.

```
Enter the number matching the USB storage device [0 or q for quit]
```

```
Unmounting external storage (/dev/sdb)...[ DONE ]
```

```
Warning!
```

```
All data on /dev/sdb will be lost!
```

```
Continue? (y/[n])
```

```
y
```

### 4. Enter **y** to wipe the device and prepare it for log file storage.

All existing data on the device is destroyed!

```
Warning!
```

```
All data on /dev/sdc will be lost!
```

```
Continue? (y/[n])
```

```
Removing master boot record...[ DONE ]
```

```
Creating ext3 filesystem...
```

```
mke2fs 1.41.14 (22-Dec-2010)
```

```
Filesystem label=CUDASTORAGE
```

```
OS type: Linux
```

```
Block size=4096 (log=2)
```

```
Fragment size=4096 (log=2)
```

```
Stride=0 blocks, Stripe width=0 blocks
```

```
247008 inodes, 986624 blocks
```

```
0 blocks (0.00%) reserved for the super user
```

```
First data block=0
```

```
Maximum filesystem blocks=1010827264
```

```
31 block groups
```

```
32768 blocks per group, 32768 fragments per group
```

```
7968 inodes per group
```

```
Superblock backups stored on blocks:
```

```
32768, 98304, 163840, 229376, 294912, 819200, 884736
```

```
Writing inode tables: done
```

```
Creating journal (16384 blocks): done
```

```
Writing superblocks and filesystem accounting information: done
```

```
This filesystem will be automatically checked every 36 mounts or  
180 days, whichever comes first. Use tune2fs -c or -i to override.
```

```
[ DONE ]
```

```
Deactivating filesystem check...[ DONE ]
```

```
[2016-05-16 09:09 CEST] [-root shell-] [-Barracuda Networks-]
```

```
[root@F101:/mnt/cudastorage]#
```

## Step 2. Enable External Log File Storage

1. Go to **CONFIGURATION > Configuration Tree > Box > Advanced Configuration > Log**

### Cycling.

2. Click **Lock**.
3. From the **External Log File Storage** list, select **yes**.

**Common Settings**

Verbose Logging	<input type="text" value="yes"/>		
External Log File Storage	<input type="text" value="yes"/>		

4. Click **Send Changes** and **Activate**.

### Next Step

Configure log file cycling. You can now use the **move to external storage** action to rotate log files to the external storage device.

For more information, see [Log File Handling](#).

### Viewing Log Files on the External Storage

To view log files stored on the external storage device, go to **LOGS** and select the external storage from the **Range** list.

## Figures

1. external\_log\_storage\_control\_timeout01.png
2. prep\_usb\_storage\_01.png
3. prep\_usb\_storage\_02.png
4. prep\_usb\_storage\_03.png
5. prep\_usb\_storage\_04.png

© Barracuda Networks Inc., 2020 The information contained within this document is confidential and proprietary to Barracuda Networks Inc. No portion of this document may be copied, distributed, publicized or used for other than internal documentary purposes without the written consent of an official representative of Barracuda Networks Inc. All specifications are subject to change without notice. Barracuda Networks Inc. assumes no responsibility for any inaccuracies in this document. Barracuda Networks Inc. reserves the right to change, modify, transfer, or otherwise revise this publication without notice.